

# KODAK *Ektapro* CR Imager, Model 2000

The KODAK EKTAPRO CR Imager, Model 2000 combines high frame rates and excellent resolution digital imaging within a small, portable, self-contained package. The CR Imager offers record rates up to 2000 frames per second, continuous recording with variable pre/post trigger, and both live and playback video as color or monochrome RS-170 output. Playback can be performed instantly at a variety of speeds. A hand-held keypad provides easy, intuitive access to most system features.

## SELF-CONTAINED, COMPACT DESIGN

Designed as a small, lightweight, self-contained camera, the CR Imager does not require an accompanying processor. Digital images may be stored during download in a compact (Bayer) or industry standard 24-bit Color TIFF format onto a PCMCIA hard drive or solid state memory card for future detailed analysis using a notebook or desktop computer. The CR Imager's one-button record and auto exposure features reduce the imaging process to a single TTL or contact closure. Sophisticated color balancing provides superior image quality in a wide range of lighting conditions. The adjustable X/Y coordinate display, in addition to

record, playback, and download functions, make basic analysis and permanent storage of images a simple task. By attaching a video recorder to the rear of the camera, an operator can capture and store images to S-VHS tape.

## NETWORKING AND COMMUNICATIONS

100 Mbps Ethernet communication is a standard feature, providing remote control and fast digital image transfer for the CR Imager from a personal computer. PC-based control software supports both 100BASE-T Ethernet and RS-485 communication networks for simultaneous management of multiple imagers. A Dynamic Link Library is available for sophisticated users who intend to develop their own control software. And finally, an RS-232 interface allows the CR Imager to be computer controlled through an extensive built-in ASCII command set that permits easy terminal control, and development of basic software routines to automate the imaging process.

### • High-Resolution Color Recording

Kodak's state-of-the-art sensor technology provides resolution of 512 x 384 pixels in 24-bit color. Also available is a model with a monochrome sensor which provides even greater resolving power and light sensitivity.

### • Large Square Pixels

Pixels are 16 $\mu$ m x 16 $\mu$ m, making the camera ideal for computer image analysis applications.

### • Unique Anti-Blooming Control

The camera can look directly into flood lamps and still capture the surrounding scene. This is unique for high-speed sensors.

### • Built-in Electronic Shutter

The camera's reliable electronic shutter provides sharp images and is essential in eliminating motion blur.

### • Variable Exposure

From 23 through 983 microseconds at 1,000 full frames per second, in 5 microseconds increments.

### • Hand-held Keypad

The keypad provides comprehensive, easy-to-use access to system functions.



*The EKTAPRO CR Imager, Model 2000 with hand-held keypad.*



MOTION ANALYSIS SYSTEMS DIVISION



# KODAK EKTAPRO CR Imager, Model 2000

## SPECIFICATIONS



- Resolution:** 512 (H) x 384 (V) photo-sensitive pixels  
**Image:** 24-bit color or 8-bit monochrome images
- Blooming Protection:** Greater than 100x at 1 millisecond exp. 1000 frames per second (fps)
- Exposure Rates:** Electronic shutter variable from 23 through 983 $\mu$ s at 1,000 full fps, in 5 $\mu$ s increments
- Dynamic Range:** 48 dB at 25°C ambient temperature
- Record Rate:** NTSC = 2000, 1000, 500, 250, 125, 60 and 30 fps  
PAL = 2000, 1000, 500, 250, 125, 50, 25 fps and external
- Trigger Modes:** Variable from start to maximum available image capacity
- Playback Rates:** NTSC = 1, 2, 3, 7, 15 and 30 fps  
PAL = 1, 2, 3, 6, 12 and 25 fps
- Recording Times:** 2 seconds storage at 1000 full fps; 2.73 seconds storage at 2000 fps;  
Longer record times at slower frame rates
- Rear Panel Controls:** Download, Live-normal/Play forward, Live-low light/Play reverse,  
Frame Rate (up/down), Exposure Time (up/down), Ready, Record, Delete Recording and RS-485  
Termination On/Off switch
- X-Y Reticle:** Built in electronic crosshair for data reduction and calibrated measurements
- Triggers:** TTL, closed contact; software driven one button record mode
- Border Data:** Date, ID number, IP address, exposure rate, frame number, trigger status, temperature, reticle  
position, system status
- LED Indicators:** Standby, Ready, Data Secure, Fault
- Hand-held Keypad:** For control of system operation. Windows™ CE compliant. Cable length is 6 feet.
- Hardwired Controls:** **Ready** - (input) changes imager mode from Standby to Ready to be Triggered  
**Trigger** - (input) changes the imager mode from Ready to Record  
**Ready Status** - (output) indicates the imager is in the Ready to record mode, waiting for Trigger  
**Fault** - (output) indicates trigger fault, PCMCIA fault, overtemp
- Computer Interfaces:** **RS-485** - used for control and configuration of one or more imagers over serial line  
**RS-232** - used for control and configuration of single imager over serial line  
**Dedicated Ethernet** - 100 Base-T physical link using UDP/IP protocol.  
Used for CR Imager control and configuration, and for downloading images from one or more  
CR Imagers. It is recommended that only CR Imagers, HG Imagers, and RO Imagers, be connected to the  
dedicated ethernet network.
- Image Capacity:** **Standard:** 2048 full frames at 1000 fps, 5461 frames at 2000 fps  
Memory module - PCMCIA type III interface for archiving digital images onto removable storage media
- Imager Connectors:** **Main Interface:** Single Mil-C-38999 connector provides a conduit for all supported communication  
lines and power  
**RS-232:** DB9 provides serial communications for control via ASCII commands  
**BNC:** Allows NTSC or PAL, RS170 video output
- Distribution Box Connectors:** **RS-485:** DB9 supports multiple imager control on a single communication line  
**RS-232:** DB9 provides serial communications for control via built-in ASCII commands  
**BNC Connection:** Ready, Exposure out, Sync In, Fault Status, NTSC or PAL Video, Trigger, and Ready Status  
**RJ45:** PC - Supports direct connection from an Imager to an Ethernet HUB  
**Power:** +22 to 42 VDC Input  
**Imager:** Single Mil-C-38999 connector provides a conduit for all supported communication lines and power  
**Output:** Single Mil-C-38999 connector provides a conduit for all supported communication  
lines and for distribution to J-Box  
**IRIG:** Optional PC based IRIG time capture for annotation of image tag data with IRIG time
- Lens Mount:** C-mount  
**Size:** 4.4"(W) x 6.2"(H) x 12.0"(L) excluding handle; 112mm (W) x 157mm (H) x 305mm (L) excluding handle  
**Weight:** 12.8 lbs. (5.8kg) excluding handle  
**Base Mounting:** Five 1/4" - 20 bolt mounts on the bottom
- Power:** +22 to 42 VDC at 50W  
**Operating Case Temp:** -10°C to +50°C  
**Storage Case Temp:** -25°C to +65°C
- Emission Standards:** Meets all applicable international standards  
**Safety Standards:** Meets all applicable international standards

**Software:** Control panel software for remote control of one or more imagers via Ethernet or RS-485; for use with  
personal computer using Windows NT 4.0™



EASTMAN KODAK COMPANY  
Motion Analysis Systems Division  
11633 Sorrento Valley Rd.  
San Diego, California 92121-1097  
TEL (858) 535-2929  
FAX (858) 792-3179  
E-MAIL: masdkodak@aol.com  
WEB SITE: www.masdkodak.com

Specifications subject to  
change without notice.

KODAK and EKTAPRO  
are trademarks of  
Eastman Kodak Company.  
Trademarks are owned by their  
respective companies.  
© Eastman Kodak Company, 1998.  
Printed in the U.S.A. N8316995K

